DIAGNOSIS AND TESTING

Pinpoint Tests — OSC Equipped Vehicles

Special Tool(s)

	Transmission Fluid Pressure Gauge 307-004 (T57L-77820-A)
ST1565-A	
	73 III Automotive Meter 105-R0057 or equivalent
ST1137-A	
	Trans Tester TR/MLP Overlay and Manual 007-00131 or equivalent

(Continued)

Special Tool(s)

a de la de l	Worldwide Diagnostic System (WDS) 418-F224
	New Generation Star (NGS) Tester 418-F205 or equivalent
ST2332-A	
ST1632-A	MLP-TR Cable 418-F107 (007-00111) or equivalent
	Transmission Tester 307-F016 (007-00130) or equivalent
ST1389-A	

Shift Solenoid Pre-Diagnosis

Any time an electrical connector or solenoid body is disconnected, inspect the connector for terminal condition, corrosion and contamination. Also inspect the connector seal for damage. Clean, repair or install new as necessary.

Use the following shift solenoid operation information when carrying out Pinpoint Test A.

Base Gearshift	PCM Comm-	5R55S Solenoid States						
Selector Position	anded Gear	SSA	SSB	SSC	SSD	PCA	PCB	PCC
P/N	P/N	On	Off	Off	On	L a	H/L ^b	La
R	R	On	Off	Off	On	H/L ^b	La	Чc
D5	1	On	Off	Off	On	H¢	H/L ^b	La
	2	On	Off	On	On	H/L ^b	H¢	La
	3	On	On	Off	On	H¢	H/L ^b	La
	4	Off	Off	Off	On	H¢	H/L ^b	H¢
	5	Off	Off	On	On	H¢	H¢	H¢
D4	1	On	Off	Off	On	H¢	H/L ^b	La
	2	On	Off	On	On	H/L ^b	H¢	La
	3	On	On	Off	On	H¢	H/L ^b	La
	4	Off	Off	Off	Off	H/L ^b	H¢	H¢
+/-	1	On	Off	Off	On	H¢	H/L ^b	La

Solenoid Operation Chart

Solenoid Operation Chart (Continued)

Base Gearshift	PCM Comm-		5R55S	Solenoid	States			
Selector Position	anded Gear	SSA	SSB	SSC	SSD	PCA	РСВ	PCC
	2	On	Off	On	On	H/L ^b	H¢	La
	3	On	On	Off	On	H¢	H/L ^b	La
	4	Off	Off	Off	On	H¢	H/L ^b	H¢
	5	Off	Off	On	On	H¢	H¢	H¢
3	3	On	On	Off	Off	H¢	La	H/L ^b
2	2	On	Off	On	Off	H¢	La	H/L ^b
1	1	On	Off	Off	Off	H¢	La	H/L ^b

a Low line pressure

b High/low pressure - PCM controlled

c High line pressure

Shift Solenoid Failure Mode Chart "Always Off"

Failed OFF due to powertrain control module and/or vehicle wiring concerns, solenoid electrically, mechanically or hydraulically stuck OFF.

SSA Always	Transmission Range Select Lever Position	
"OFF":	D5	D4
PCM Gear Commanded	Actua	l Gear
1	3	3
2	2	2
3	3	3
4	4	4M a
5	5	

a Manual

SSB Always	Transmission Range Select Lever Position			
"OFF":	D5	D4		
PCM Gear Commanded	Actual Gear Obtained			
1	1	1		
2	2	2		
3	1	1		
4	4	4M a		
5	5			

a Manual

SSC Always	Transmission Range Selecto Lever Position			
"OFF":	D5	D4		
PCM Gear Commanded	Actual Gear Obtained			
1	1	1		
2	1	1		
3	3	3		
4	4	4M a		
5	4			

a Manual

SSD Always	Transmission I Lever F	Range Selector Position
"OFF":	D5	D4
PCM Gear Commanded	Actual Gea	r Obtained
1	1/1M a	1/1 M ª
2	2M ^a	2M ^a
3	3/3Mª	3M ^a
4	4/4M ^a	4M ^a
5	5	

a Manual

Shift Solenoid Failure Mode Chart "Always On"

Failed OFF due to powertrain control module and/or vehicle wiring concerns, solenoid electrically, mechanically or hydraulically stuck ON.

SSA Alwavs	Transmission Range Sele Lever Position	
"ON":	D5	D4
PCM Gear Commanded	Actual Gea	r Obtained
1	1	1
2	2	2
3	3	3
4	1	1M ª
5	2	

a Manual

SSB Always	Transmission Range Select Lever Position	
"ON":	D5	D4
PCM Gear Commanded	Actual Gea	r Obtained
1	3	3
2	2	2
3	3	3
4	4	4M a
5	5	

a Manual

SSC Alwavs	Transmission Range Selecter		
"ON":	D5	D4	
PCM Gear Commanded	Actual Gea	r Obtained	
1	1/2	1/2	
2	2	2	
3	3/Ratio 1.16	3/Ratio 1.16	
4	4/5	4/5	
5	5		

SSD Always	Transmission Range Selector Lever Position		
"ON":	D5	D4	
PCM Gear Commanded	Actual Gear Obtained		
1	1	1	
2	2	2	
3	3	3	

SSD Alwavs	Transmission Range Selector Lever Position	
"ON":	D5	D4
4	4	4
5	5	

Pressure Control Solenoid Failure Mode Chart "Always Low"

	Transmission Range Selector Lever Position		
PC A "Low":	D5 D4		
PCM Gear Commanded	Actual Gea	r Obtained	
1	S a /1	1	
2	2	2	
3	S ^a /1	1	
4	S ^a /4	4M	
5	5		

a Slips

	Transmission Range Selector Lever Position	
PC B "Low":	D5 D4	
PCM Gear Commanded	Actual Gea	r Obtained
1	1	1
2	1	1
3	3	3
4	4	4
5	4	

	Transmission Range Selector Lever Position	
PC C "Low":	D5	D4
PCM Gear Commanded	Actual Gea	r Obtained
1	1	1
2	2	2
3	3	3
4	3	3
5	1.1	

Pressure Control Solenoid Failure Mode Chart "Always High"

	Transmission Range Selector Lever Position	
PC A "High":	D5	D4
PCM Gear Commanded	Actual Gea	r Obtained
1	1	1
2	2	2
3	3	3
4	4	4M a
5	5	

a Manual

	Transmission Range Selector Lever Position		
PC B "High":	D5	D4	
PCM Gear Commanded	Actual Gear Obtained		
1	1	1	

	Transmission Range Selector Lever Position	
PC B "High":	D5	D4
2	2	2
3	3	3
4	4	4M a
5	5	

a Manual

	Transmission Range Selector Lever Position	
PC C "High":	D5	D4
PCM Gear Commanded	Actual Gea	r Obtained
1	1	1
2	2	2
3	3	3
4	4	4M ^a
5	5	

a Manual

Pinpoint Tests

PINPOINT TEST A: SHIFT AND TORQUE CONVERTER CLUTCH SOLENOIDS

NOTE: Refer to the Transmission Vehicle Harness Connector illustration preceding these pinpoint tests.

NOTE: Refer to the Internal Harness Diagram illustration preceding these pinpoint tests.

NOTE: Read and record all DTCs. All Digital TR Sensor and VSS DTCs must be repaired before entering Output State Control (OSC).

	Test Step	Result / Action to Take
A1	ELECTRONIC DIAGNOSTICS	
	 Key in OFF position. Select PARK. Check to make sure the transmission harness connector is fully seated, terminals are fully engaged in connector and in good condition before proceeding. Connect the diagnostic tool. Key in ON position. Enter the following diagnostic mode on the diagnostic tool: Diagnostic Data Link. Enter the following diagnostic mode on the diagnostic tool: PCM. Enter the following diagnostic mode on the diagnostic tool: PCM. Enter the following diagnostic mode on the diagnostic tool: Active Command Modes. Enter the following diagnostic mode on the diagnostic tool: Output State Control (OSC). Enter the following diagnostic mode on the diagnostic tool: Trans-Bench Mode. Does vehicle enter Trans-Bench Mode? 	Yes REMAIN in Trans-Bench Mode. GO to A2. No REPEAT procedure to enter Trans-Bench Mode. If vehicle did not enter Trans-Bench Mode, REFER to thePowertrain Control/Emissions Diagnosis (PC/ED) manual for diagnosis of PCM or NGS.
A2	WIGGLE TEST	
	Remain in Trans-Bench Mode.Select PIDs to be monitored.	

PINPOINT TEST A: SHIFT AND TORQUE CONVERTER CLUTCH SOLENOIDS (Continued)

A2 WIGGLE TEST (Continued) PID Command PID Actual SSA SSA SSB SSB SSC SSC SSD SSD TCC TCC • Select "ON" to turn suspect solenoid on. • Press "SEND".	
PID Command PID Actual SSA SSA SSB SSB SSC SSC SSD SSD TCC TCC • Select "ON" to turn suspect solenoid on. • Press "SEND".	
Pib Command Pib Actual SSA SSA SSB SSB SSC SSC SSD SSD TCC TCC • Select "ON" to turn suspect solenoid on. • Press "SEND".	
SSA SSA SSB SSB SSC SSC SSD SSD TCC TCC • Select "ON" to turn suspect solenoid on. • Press "SEND".	
SSB SSB SSC SSC SSD SSD TCC TCC • Select "ON" to turn suspect solenoid on. • Press "SEND".	
SSC SSC SSD SSD TCC TCC • Select "ON" to turn suspect solenoid on. • Press "SEND".	
SSD SSD TCC TCC • Select "ON" to turn suspect solenoid on. • Press "SEND".	
TCC TCC Select "ON" to turn suspect solenoid on. Press "SEND".	
 Select "ON" to turn suspect solenoid on. Press "SEND". 	
 Wiggle all wiring and connectors to the transmission. Monitor the solenoid state for changes. Select "OFF" to turn solenoid off. Press "SEND". Does the suspect solenoid(s) fault state change? A3 SOLENOID FUNCTIONAL CHECK Monitor each solenoid state. Turn each solenoid ON and OFF. Does the solenoid turn ON and OFF when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and com solenoid turn on and off when commanded and compared to the solenoid turn on and the solenoid turn on and the solenoid turn on and tu	es EPAIR the circuit. TEST the system for ormal operation. O to A3. es O to A4. o
Can solehold activation be heard?	O to A5.
 Carry out OSC Trans-Drive Mode. Select GEAR for shift solenoids or follow procedures for GEAR as listed in this section. Select TCC for Torque Converter Clutch Solenoid. Follow procedures of TCC in Drive Mode as listed in this section. Does the transmission upshift and downshift or torque converter engage/disengage when commanded? 	es LEAR all DTCs. ROAD TEST to verify if oncern is still present. If concern is still resent, REFER to Diagnosis By Symptom o diagnose shift or torque converter oncern. 0 O to A5.
A5 CHECK FOR BATTERY VOLTAGE	
 Disconnect: Transmission Vehicle Harness Connector. Visually inspect all wires and connectors for damage. Key in ON position. Measure the voltage on pin 3 harness side and ground. 	
A0005135 • Is the voltage greater than 10 volts?	es O to A6. O EPAIR the circuit. TEST for normal beration.

PINPOINT TEST A: SHIFT AND TORQUE CONVERTER CLUTCH SOLENOIDS (Continued)



PINPOINT TEST A: SHIFT AND TORQUE CONVERTER CLUTCH SOLENOIDS (Continued)



PINPOINT TEST B: TRANSMISSION FLUID TEMPERATURE (TFT) SENSOR

NOTE: Refer to the Transmission Vehicle Harness Connector illustration preceding these pinpoint tests.

	Test Step	Result / Action to Take
B1	ELECTRONIC DIAGNOSTICS	
B2	 Key in OFF position. Select PARK. Check to make sure the transmission harness connector is fully seated, terminals are fully engaged in connector and in good condition before proceeding. Connect the diagnostic tool. Key in ON position. Select Diagnostic Data Link. Select PID/Data Monitor and Record. Enter the following diagnostic mode on the diagnostic tool: PIDs; TFT, TFTV. Does the vehicle enter PID/Data Monitor and Record? WARM-UP/COOL-DOWN CYCLE While monitoring the TFT PIDs, carry out the following test: If transmission is cold, run transmission to warm it up. If transmission is warm, allow transmission to cool down. Do the TFT PIDs increase as the transmission is warmed up or decrease as the transmission is cooled or does the TFT or TFTV drop in and out of range? 	Yes REMAIN in PID/Data Control. GO to B2. No REPEAT procedure to enter PID. If vehicle did not enter PID, REFER to thePowertrain Control/Emissions Diagnosis (PC/ED) manual for diagnosis of PCM and NGS. Yes If the TFT PIDs increase as the transmission is warmed or decrease as the transmission is cooled, CLEAR all DTCs. ROAD TEST to verify if concern is still present. If concern is still present, REFER to Diagnosis By Symptom in this section to diagnose transmission overheating. If the TFT or TFTV drop in and out of range, INSPECT for intermittent concern in the internal/external harness, sensor or connector. No
B3	ELECTRICAL SIGNAL CHECK	
	 Disconnect: Transmission Harness Connector. Visually inspect all wires and connectors for damage.]
		(Continued)

PINPOINT TEST B: TRANSMISSION FLUID TEMPERATURE (TFT) SENSOR (Continued)

	Test Step	n .	Result / Action to Take
B3 ELECTRICAL SIG		-	
Measure the vo	bitage between pin 2 harn	ess side and ground.	
A0005138		Yes GO to B4 . No REPAIR the circuit. TEST the system for	
Is the voltage	between 4.5 and 5.0 vol	ts?	normal operation.
Measure the re body connector	sistance between pin 2 a	nd 12 at the solenoid	-
A0061762 • Record the resistance. • Resistance should be approximately in the following ranges:			
۵°	° F	Resistance (Ohms)	
-40 to -20	-40 to -4	967K - 284K	
-19 to -1	-3 - 31	284K - 100K	
0 - 20	32 - 68	100K - 37K	
21 - 40	69 - 104	37K - 16K	
41 - 70	105 - 158	16K - 5K	
71 - 90	159 - 194	5K - 2.7K	
91 - 110	195 - 230	2.7K - 1.5K	Yes
111 - 130	231 - 266	1.5K - 0.8K	REFER to Diagnosis By Symptom in this section to diagnose an overheating
131 - 150	267 - 302	0.8K - 0.54K	concern.
Is the resistant	ce in the range?		NO INSTALL a new solenoid body assembly.

PINPOINT TEST C: DIGITAL TRANSMISSION RANGE (TR) SENSOR

NOTE: Refer to the Digital Transmission Range (TR) Sensor Connector illustration and Digital Transmission Range TR) Sensor Diagnosis Chart preceding these pinpoint tests.

	Test Step	Result / Action to Take
C1	VERIFY DIAGNOSTIC TROUBLE CODES	
	Key in OFF position. Select DARK	Yes
	 Select PARK. Carry out on-board diagnostic test. 	GO 10 C4.
	Are only DTC codes P0705, P0708 present?	GO to C2.
C2	VERIFY DIGITAL TRANSMISSION RANGE SENSOR ALIGNMENT	
	Key in OFF position. Select PARK	
	 Check to make sure the digital TR sensor harness connector is 	Vos
	fully seated, terminals are fully engaged in connector and in	GO to C3.
	 Apply the parking brake. 	No
	Select NEUTRAĽ.	ADJUST the digital TR sensor; REFER
	 Disconnect the shift cable/linkage from the manual lever. Verify that the TR Sensor Alignment Gauge fits in the 	in this section. PLACE transmission range
	appropriate slots.	selector lever into PARK and CLEAR
	Is the digital TR sensor correctly adjusted?	DTCs. RERUN OBD Tests. GO to C3.
C3		Vec
	 Place range selector lever in D5. Connect the shift cable/linkage. 	res GO to C4
	Verify that the shift cable/linkage is correctly adjusted. Refer	No
	toSelector Lever Cable Adjustment in this section.	ADJUST the shift cable/linkage. REFER
	is the shift custominage is correctly adjusted.	toSelector Lever Cable Adjustment in this section. GO to C4
C4	CHECK ELECTRICAL SIGNAL OPERATION	
	Select PARK.	
	Disconnect: Digital TR Sensor.	Yes
	CAUTION: Do not pry on connector. This will damage	REPAIR as necessary. CLEAR DTCs and
	the connector and result in a transmission concern.	RERUN OBD Tests.
	Press button and pull out on the digital TR harness connector.	NO
	 Inspect both ends of the connector for damage of pushed out pins, corrosion, loose wires and missing or damaged seals. 	If diagnosing a starting concern or a
	 Is there damage to the connector, pins or harness? 	backup lamp concern, GO to C10.
C5	CHECK ELECTRICAL SYSTEM OPERATION (DIGITAL TR AND	
	Key in OFE position	
	Connect the diagnostic tool.	
	Connect: Digital TR Sensor. Key in ON position	
	Enter the following diagnostic mode on the diagnostic tool: TR	
	PIDS TR_D, TR_V.	
	 Observe the PIDs, TR_D, and TR_V (vehicle-dependent) while 	Yes
	wiggling harness, tapping on sensor, or driving the vehicle. Use	The problem is not in the digital TR sensor
	TR_V for DTC P0708.	system. REFER to Diagnosis By Symptom
	Compare the PIDs to the Digital Transmission Range (TR) Senser Diagnasis Chart	No
	 Sensor Diagnosis Chart. Do the PIDs TR D and TR V match the Digital 	If TRD changes when wiggling harness,
	Transmission Range (TR) Sensor Diagnosis chart, and does	tapping on the sensor or driving the
	the IR_D PID remain steady when the harness is wiggled, the sensor is tapped on, or the vehicle driven?	GO to C6
		00 10 00.

PINPOINT TEST C: DIGITAL TRANSMISSION RANGE (TR) SENSOR (Continued)

Test Step	Result / Action to Take
C6 CHECK DIGITAL TRANSMISSION RANGE SENSOR OPERATION	
 Disconnect: Digital TR Sensor. Connect: TR-E Cable to Transmission Tester. Connect: TR-E Cable to Digital TR Sensor. Place the DIGITAL TR Overlay onto Transmission Tester. Carry out SENSOR Test as instructed on the digital TR Overlay. Does the status lamp on the tester TRS-E cable match the selected gear positions? 	Yes Concern is not in the digital TR sensor. GO to C7. NO INSTALL a new digital TR sensor and ADJUST. REFER toDigital Transmission Range (TR) Sensor in this section. CLEAR DTCs and RERUN OBD Tests.
C7 CHECK PCM HARNESS CIRCUITS FOR OPENS	
 Key in OFF position. Disconnect: 150 Pin PTEC Module Connector "B". Inspect for damaged or pushed out pins, corrosion or loose wires. Disconnect: Digital TR Sensor. CAUTION: Do not pry the connector. This will damage the connector and result in a transmission concern. Disconnect the digital TR sensor connector. Measure the resistance between TR pin 2 harness side and 	
signal return PCM pin 14 harness side.	
A0003752	





PINPOINT TEST C: DIGITAL TRANSMISSION RANGE (TR) SENSOR (Continued)







PINPOINT TEST C: DIGITAL TRANSMISSION RANGE (TR) SENSOR (Continued)



PINPOINT TEST C: DIGITAL TRANSMISSION RANGE (TR) SENSOR (Continued)

	Test Step	Result / Action to Take
C10	CHECK THE NON-PCM INTERNAL CIRCUITS OF SENSOR	
	 Connect: TRS-E Cable to Transmission. Connect: TRS-E Cable to Digital TR Sensor. Place the Digital TR Overlay onto Transmission Tester. Carry out Switch Test as instructed on the digital TR Overlay. Does the status lamp on the tester indicate RED for the correct gear position? 	Yes Concern is not in the digital TR sensor. For start system concerns, REFER toSection 303-04 or Section 303-04. For backup lamp concerns, REFER toSection 417-01.
		No INSTALL a new digital TR sensor and ADJUST; REFER toDigital Transmission Range (TR) Sensor in this section. CLEAR DTCs and RERUN OBD Tests.

PINPOINT TEST D: PRESSURE CONTROL (PC) SOLENOIDS (PCA, PCB, PCC)

NOTE: Refer to the Transmission Vehicle Harness Connector illustration preceding these pinpoint tests.

NOTE: Read and record all DTCs. All digital TR Sensor and VSS DTCs must be repaired before entering Output State Control (OSC).

	Test Step	Result / Action to Take
D1	ELECTRONIC DIAGNOSTICS	
D2	 Key in OFF position. Select PARK. Check to make sure the transmission harness connector is fully seated, terminals are fully engaged in the connector and in good condition before proceeding. Install 300 psi pressure gauges into Line and PC C tap. Connect the diagnostic tool. Key in ON position. Enter the following diagnostic mode on the diagnostic tool: Diagnostic Data Link. Enter the following diagnostic mode on the diagnostic tool: Active Command Modes. Enter the following diagnostic mode on the diagnostic tool: Output State Control (OSC). Enter the following diagnostic mode on the diagnostic tool: Trans-Bench Mode. Does the vehicle enter the Trans-Bench Mode? 	Yes REMAIN in Trans-Bench Mode. GO to D2. No REPEAT procedure to enter Trans-Bench Mode. If vehicle did not enter OSC, REFER toPowertrain Control/Emissions Diagnosis (PC/ED) manual for diagnosis of PCM or NGS.
	 Monitor pressure gauges. Enter the following diagnostic mode on the diagnostic tool: Parameter; PCx. NOTE: Make sure that the solenoids not being tested are off or at zero. Select PC A, PC B, or PC C. Select value - 15, 30, 45, 60, 70 or 90 psi. Press "SEND". Select another value "0-90 psi". Press "SEND". Enter the following diagnostic mode on the diagnostic tool: XXX. Press "SEND". For PC A and PC B: Does the pressure reading for A or B follow the commanded pressure, (actual A and B pressures will be higher than the commanded pressure)? For PC C: Does the pressure reading match the commanded pressure?" 	Yes CLEAR DTCs. No GO to D3.
D3	CHECK FOR BATTERY VOLTAGE	
	 Disconnect: Transmission Harness Connector. Visually inspect all wires and connectors for damage. Key in ON position. 	

PINPOINT TEST D: PRESSURE CONTROL (PC) SOLENOIDS (PCA, PCB, PCC) (Continued)



PINPOINT TEST D: PRESSURE CONTROL (PC) SOLENOIDS (PCA, PCB, PCC) (Continued)



PINPOINT TEST E: TURBINE SHAFT SPEED (TSS), INTERMEDIATE SHAFT SPEED (ISS), AND OUTPUT SHAFT SPEED (OSS) SENSORS

NOTE: Refer to the turbine shaft speed (TSS), intermediate shaft speed (ISS), and output shaft speed (OSS) sensor connector illustrations preceding these pinpoint tests.

	Test Step	Result / Action to Take
E1	ELECTRONIC DIAGNOSTICS	
	 Check to make sure the transmission harness connectors are fully seated, terminals are fully engaged in connector and in good condition before proceeding. Connect the diagnostic tool. Key in ON position. Enter the following diagnostic mode on the diagnostic tool: Diagnostic Data Link. Enter the following diagnostic mode on the diagnostic tool: PCM. Select PID/Data Monitor and Record. Select the following PIDs: TSS, ISS, or OSS. Does vehicle enter PID/Data Monitor and Record? 	Yes REMAIN in PID/Data. GO to E2. No REPEAT procedure to ENTER PID. If vehicle did not enter PID, REFER to thePowertrain Control/Emissions Diagnosis (PC/ED) manual for diagnosis of PCM or NGS.

PINPOINT TEST E: TURBINE SHAFT SPEED (TSS), INTERMEDIATE SHAFT SPEED (ISS), AND OUTPUT SHAFT SPEED (OSS) SENSORS (Continued)

	Test Step	Result / Action to Take
E2 DRIVE CYCLE TEST		
 While monitoring th so that the transmis gears. Does the TSS, ISS decrease with eng 	e appropriate sensor PID, drive the vehicle sion upshifts and downshifts through all , or OSS Speed PID increase and ine and vehicle speed?	Yes GO to E3. No If the TSS, ISS, or OSS Speed PID does not increase and decrease with engine and vehicle speed, INSPECT for open or short in vehicle harness, sensor, a PCM concern, or internal hardware concern. GO to E4.
E3 DRIVE CYCLE TEST	ERRATIC	
 While monitoring th so that the transmis gears. Is the TSS, ISS, or zero or near zero and the transmis section that the transmis section that the transmission the transmission that the transmission that the transmission that the transmission the t	e appropriate sensor PID, drive the vehicle sion upshifts and downshifts through all OSS Speed PID signal erratic (drop to and return to normal operation)?	Yes If the sensor signal is erratic, INSPECT for intermittent concern in the harness, sensor, or connector. GO to E4. No CLEAR all DTCs. Rerun OBD.
E4 CHECK PCM HARNES	SS CIRCUITS FOR OPENS	
 Key in OFF position Disconnect: 150 Pir Inspect for damage wires. For OSS, measure appropriate sensor For OSS, measure ooooooo Ooooooo Ooooooo Ooooooo For ISS, measure th appropriate sensor 	A. PTEC Module Connector "B". d or pushed out pins, corrosion or loose the resistance between pin 17 and the connector pin 2 harness side. Here resistance between pin 17 and the connector pin 2 harness side. Here resistance between pin 17 and the connector pin 2 harness side.	
A0009270		
		(Continued)

PINPOINT TEST E: TURBINE SHAFT SPEED (TSS), INTERMEDIATE SHAFT SPEED (ISS), AND OUTPUT SHAFT SPEED (OSS) SENSORS (Continued)





PINPOINT TEST E: TURBINE SHAFT SPEED (TSS), INTERMEDIATE SHAFT SPEED (ISS), AND OUTPUT SHAFT SPEED (OSS) SENSORS (Continued)



PINPOINT TEST E: TURBINE SHAFT SPEED (TSS), INTERMEDIATE SHAFT SPEED (ISS), AND OUTPUT SHAFT SPEED (OSS) SENSORS (Continued)



PINPOINT TEST E: TURBINE SHAFT SPEED (TSS), INTERMEDIATE SHAFT SPEED (ISS), AND OUTPUT SHAFT SPEED (OSS) SENSORS (Continued)

	Test Step	Result / Action to Take
E7	CHECK SENSORS FOR SHORT TO GROUND	
	 Measure the resistance between pin 1 and 2 of each sensor and ground. 	
		Yes INSTALL a new sensor.
	A0005501	REFER to Diagnosis By Symptom for
	 Is the resistance less than 10,000 ohms? 	concerns in this section.

PINPOINT TEST F: SOLENOID MECHANICAL FAILURE

NOTE: Repair all other DTCs before repairing the following DTCs: P1714, P1715, P1716, P1717, P1740.

	Test Step	Result / Action to Take
F1	ELECTRONIC DIAGNOSIS	
	 Connect the diagnostic tool. Select PARK. Key in ON position. Carry out KOEO test until continuous DTCs have been displayed. If any of the following DTCs are present, continue with this test: P1714, P1715, P1716, P1717, P1740. Are other DTCs present for TFT or shift solenoids? 	Yes REPAIR the DTCs for TFT or shift solenoids first. CLEAR DTCs and CARRY OUT transmission Drive Cycle test. RERUN Quick Test. No INSTALL a new solenoid and/or body. REFER to the Diagnostic Trouble Code Charts for code description. GO to F2.
F2	TRANSMISSION DRIVE CYCLE TEST	
	 Carry out transmission drive cycle test. Refer to Transmission Drive Cycle Test in this section. Does the vehicle upshift and downshift OK? 	Yes GO to F3. No REFER to Diagnosis By Symptom in this section to diagnose shift concerns.
F3	RETRIEVE DTCS	
	 Connect the diagnostic tool. Select PARK. Key in ON position. Carry out KOEO test until continuous DTCs have been displayed. Are DTCs P1714, P1715, P1716, P1717, P1740 still present? 	Yes INSTALL a new PCM. ROAD TEST and RERUN Quick Test. No Testing completed. If a concern still exists, REFER to Diagnosis By Symptom in this section for concern diagnosis.

PINPOINT TEST G: REVERSE PRESSURE SWITCH

NOTE: Refer to the Reverse Pressure (RP) Switch Diagnosis Chart preceding these pinpoint tests.

Test Step		Result / Action to Take
G1	ELECTRONIC DIAGNOSIS	
	Key in OFF position.Select PARK.	

PINPOINT TEST G: REVERSE PRESSURE SWITCH (Continued)

	Test Step	Result / Action to Take
G1	ELECTRONIC DIAGNOSIS (Continued)	
	 Check to make sure that the transmission harnesses is fully seated, the terminals are fully engaged in the connector, and the terminals are in good condition. Connect the diagnostic tool. Key in ON position. Select Diagnostic Data Link. Select PCM. Select PID DATA Monitor and record. Enter the following diagnostic mode on the diagnostic tool: PIDs: RPS, FFG RPS. Does the vehicle enter PID/DATA Monitor and record? 	Yes REMAIN in PID/DATA control. GO to G2. No REPEAT the procedure. If vehicle did not enter PID, REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual for PCM and NGS.
G2	ELECTRICAL SIGNAL CHECK	
	 Carry out Transmission Drive Cycle Test and monitor line pressure and PIDs: RPS, FFG RPS. Do the PIDs: RPS, FFG RPS match the chart for a given gear? 	Yes RP switch is OK. REFER to Diagnosis By Symptom in this section. No GO to G3.
G3	CHECK HARNESS FOR OPENS	
	 Key in OFF position. Disconnect: 150 Pin PTEC Module Connector "B". Disconnect: Transmission Connector. Measure the resistance between PCM pin 30 and pin 13 harness side. 	
	A0037855	
	 Measure the resistance between PCM pin 17 and pin 12 harness side. 	
		Yes
	A0037854	GO to G4.
	Are the resistances less than 5 ohms?	REPAIR the circuit. CLEAR DTCs. RERUN OBD tests.
		(Continued)

PINPOINT TEST G: REVERSE PRESSURE SWITCH (Continued)

