

2. Use a hexagonal wrench to remove the wrench bolts (24, 25) and disassemble the rear cover (23) assembly from the body (1).




Figure 12

3. Disassemble the spring (19) to remove the break piston (17) and disassemble it from the body (1) using a jig.




Figure 13




Figure 14

4. Remove cylinder block assembly, friction plate (15), and plate (16) from body (1).

NOTE: Pay attention to order of plates and friction plates.




Figure 15




Figure 16

5. Remove shoe plate (8) from body (1).




Figure 17

6. Remove snap ring (4) from body (1) using snap ring pliers jig.
7. Turn body over, and separate shaft (5) assembly using steel bar.




Figure 18



Figure 19

Disassembly of the cylinder block subassembly

8. Separate piston assembly (14) and the set plate (13) from cylinder block assembly.




Figure 20

FG000696




Figure 21

FG000697

9. Remove friction plate (15), plate (16), ball guide (12), ball guide seat (11) and spring (10) from cylinder block (9).




Figure 22

FG000698





Figure 23

FG000699




FG000700

Figure 24

Disassembly of the rear cover subassembly

10. Separate valve plate (20) from rear cover (23).



FG000701


Figure 25



FG005150


Figure 26

11. Remove two relief valve assemblies (30) from rear cover (23) with torque wrench.



FG000706


Figure 27



FG000707


Figure 28

12. Remove check valve assemblies from rear cover (23) with L wrench, and disassemble it in order of plug (28), spring (27), and poppet (26).



FG000708

Figure 29



FG000709

Figure 30

13. Remove plug (35) from rear cover (23) with L wrench and disassemble it in order of backup ring (37), O-ring (36), O-ring (38) and anti-inversion valve assembly (34).




Figure 31

FG000710




Figure 32

FG000711




Figure 33

FG000712

CLEANING AND INSPECTION (WEAR LIMITS AND TOLERANCES)

For general cleaning and inspection procedures, refer to "General Maintenance Procedures" section.


REASSEMBLY

General Cautions

1. Wash and clean each part. Then dry them with compressed air. The friction plate, however, should not be washed with treated oil.
2. Each connecting parts should be tightened according to its assigned torque.
3. Only use a plastic soft-faced hammer.

Reassembly of drive shaft subassembly

1. Put roll bearing (3) on a heater and apply heat to their inner race (inlet temperature: 290°C for 2 minutes).



FG001328

Figure 34




Figure 35

2. Assemble heated roll bearing (3) into the shaft (5). Use a pliers jig to assemble install stop ring (7).




Figure 36

FG000716




Figure 37

FG000717

3. Assemble oil seal (2) in body (1) using bar hammer.




Figure 38


FG000719



Figure 39

FG005151

4. Install shaft in body (1) using bar hammer.



FG000717


Figure 40



FG005152

Figure 41

5. Secure shaft with snap ring (4) using snap ring pliers.



FG000722

Figure 42



FG005149

Figure 43

6. Coat shoe plate (8) with grease, and assemble it into body.




Figure 44

FG000724




Figure 45

FG005153

Assembly of Cylinder Block Assembly Subassembly

7. Insert nine sets of springs (10) in cylinder block (9).




Figure 46

FG000726




Figure 47

FG000727

8. Insert ball guide seat (11) and ball guide (12) in cylinder block (9).




Figure 48

FG000728




Figure 49

FG000729




Figure 50

FG000759




Figure 51

FG000730