

## 7-8 ENGINE BOTTOM END/TRANSMISSION

### Crankcase

#### Crankcase Assembly

##### CAUTION

**Right and left crankcase halves are machined at the factory in the assembled state, so they must be re-placed together as a set.**

- Chip off the old gasket from the mating surfaces of the crankcase halves, and clean off the crankcase with a high flash-point solvent. After cleaning, apply engine oil to the transmission gears, shift drum, shift forks and bearings.
- Be sure to replace any oil seal removed with a new one. Press in the new oil seal using a press and suitable tools so that the seal surface is flush with the surface of the crankcase.
- Apply high temperature grease to the oil seal lips.
- Press in the ball bearings using the bearing driver set until the bearing is bottomed.

**Special Tools - Bearing Driver Set: 57001-1129**

- ★ If the crankshaft bearings stay on the crankshaft when splitting the crankcase, remove the bearings from the crankshaft and reinstall them in the crankcase as follows.
- Remove the bearings from the crankshaft with a bearing puller.

**Special Tools - Bearing Puller Adapter: 57001-136 [B]  
Bearing Puller: 57001-158 [A]**

- Discard the bearing that is removed from the crankshaft.
- Position the crankcase half so that the main bearing housing is seated on a suitable press fixture.
- Press each crankshaft bearing [B] until it bottoms out using a bearing driver [A] from the driver set which contacts the bearing outer race.

**Special Tool - Bearing Driver Set: 57001-1129 [A]**




- Install the crankshaft bearing so that the ball retainer side faces in (to the oil seal [C] side).

- Turn the crankshaft to BDC, and install the crankshaft jig between the crankshaft flywheels to protect flywheel alignment and press the crankshaft into the right crankcase half.

**Special Tool - Crankshaft Jig: 57001-1174**

- Install the transmission shaft (see Transmission Shaft Installation).
- Check to see that the crankcase knock pins are in place on the right crankcase half. If any of them has been removed, replace it with a new one.
- Apply liquid gasket to the mating surface of the left crankcase half.

**Sealant - Kawasaki Bond (Liquid Gasket - Silver): 92104-002**



### Crankcase

- The crankshaft jig must be installed between the flywheel opposite the connecting rod big end with the crankshaft at BDC. This is to protect flywheel alignment
  - [A] Crankshaft
  - [B] Connecting Rod
  - [C] Crankshaft Jig: 57001-1174
- Using a suitable tool on the left crankcase to press around the hole for the crankshaft, fit the crankcase halves together with a press on the tool.
  - [A] Press
  - [B] Connecting Rod
  - [C] Crankshaft Jig


#### NOTE

○ *Constantly check the alignment of the two crankcase halves, the position of the transmission shafts, and shift drum. The front and rear of the crankcase must be pushed together evenly.*

- Remove the crankshaft jig from the flywheel.
- Tighten the crankcase bolts to the specified torque starting with the ones around the crankshaft, and then the farther ones.

**Torque - Crankcase Bolts: 8.8 N·m (0.90 kgf·m, 78 in·lb)**

- Check to see that the crankshaft, drive shaft, and output shaft all turn freely (in the neutral position).
- ★ If the crankshaft will not turn, probably the crankshaft is not centered; tap the appropriate end of the crankshaft with a mallet to reposition it.
- Spinning the output shaft, shift the transmission through all the gears to make certain there is no binding and that all the gears shift properly.
- Assemble the engine.
- Install:
  - Clutch (see Engine Right Side chapter)
  - Magneto Fly Wheel and Stator (see Electrical System chapter)
  - Engine (see Engine Removal/Installation chapter)



## 7-10 ENGINE BOTTOM END/TRANSMISSION

### Crankshaft, Connecting Rod

---

#### *Crankshaft Removal*

- See Crankcase Splitting.

#### *Crankshaft Installation*

- See crankcase Assembly.

#### *Crankshaft Disassembly*

Since assembly of the crankshaft demands exacting tolerances, the disassembly of the crankshaft can only be done by a shop having the necessary tools and equipment.

- If it should be necessary to disassemble the crankshaft, use a press to remove the crankpin.

#### *Crankshaft Assembly*

Since the assembly of the crankshaft demands exacting tolerances, the disassembly and reassembly of the crankshaft can only be done by a shop having the necessary tools and equipment.

- Check that the connecting rod radial clearance is within specification (see Connecting Rod Big End Radial Clearance Inspection).
- Press the crank halves onto the crankpin until the connecting rod side clearance is within specification (see Connecting Rod Big End Side Clearance Inspection).
- Adjust crankshaft runout until it is within specification (see Crankshaft Runout Inspection).

#### *Big End Seizure Inspection*

- ★ In case of serious seizure with damaged flywheels, the crankshaft must be replaced.
- ★ In case of less serious damage, disassemble the crankshaft and replace the crankpin, needle bearing, side washers, and connecting rod.

#### *Crankshaft Bearing Inspection*

Since the ball bearings are made to extremely close tolerances, the wear must be judged by feel rather than measurement.


- Remove the following.
  - Piston (see Engine Top End chapter)
  - Primary Gear (see Engine Right Side chapter)
- Turn the crankshaft, using the connecting rod.
- ★ If the bearings are noisy, do not spin smoothly, or have any rough spots, replace them.

**Torque - Primary Gear Nut: 49 N·m (5.0 kgf·m, 36 ft·lb)**

## Crankshaft, Connecting Rod

### Connecting Rod Big End Radial Clearance Inspection

- Set the crankshaft in a flywheel alignment jig or on V blocks, and place a dial gauge against the connecting rod big end.
- Push the connecting rod first towards the gauge and then in the opposite direction. The difference between the two gauge readings is the radial clearance.
- ★ If the radial clearance exceeds the service limit, the crankshaft should be either replaced or disassembled and the crankpin, needle bearing, and connecting rod big end examined for wear.



### Connecting Rod Big End Radial Clearance

**Standard:** 0.029 ~ 0.041 mm (0.0011 ~ 0.0016 in.)

**Service Limit:** 0.09 mm (0.0035 in.)


### Connecting Rod Big End Side Clearance Inspection

- Set the crankshaft on V blocks.
- Measure the side clearance [A] of the connecting rod with a thickness gauge.
- ★ If the clearance exceeds the service limit, replace the crankshaft.

### Connecting Rod Big End Side Clearance

**Standard:** 0.40 ~ 0.50 mm (0.016 ~ 0.20 in.)

**Service Limit:** 0.7 mm (0.028 in.)



### Crankshaft Runout Inspection


- Set the crankshaft on V blocks, and place a dial gauge against the points indicated.
- Turn the crankshaft slowly. The maximum difference in gauge readings is the crankshaft runout.

### Crankshaft Runout

**Standard:** TIR 0.03 mm (0.0012 in.) or less

**Service Limit:** TIR 0.08 mm (0.0031 in.)

**[B] 7.5 mm (0.30 in.)**





## 7-12 ENGINE BOTTOM END/TRANSMISSION

### Crankshaft, Connecting Rod

#### *Crankshaft Alignment Inspection*

- ★ If the runout at either point exceeds the service limit, align the flywheels so that the runout falls within the service limit.
- In the case of horizontal misalignment, which is the most common, strike the projecting rim of the flywheel with a plastic, soft lead, or brass hammer as indicated in the figure.
- Recheck the runout with a dial gauge, repeating the process until the runout falls within the service limit.
- Vertical misalignment is corrected either by driving a wedge in between the flywheels or by squeezing the flywheel rims in a vise, depending on the nature of the misalignment. In cases of both horizontal and vertical misalignment, correct the horizontal misalignment first.
- ★ If flywheel misalignment cannot be corrected by the above method, replace the crankpin or the crankshaft itself.


|  |
|--|
| <b>CAUTION</b>                                 |
| <b>Don't hammer the flywheel at point "A".</b> |



## Transmission

### Transmission Shaft Removal

- Split the crankcase (see Crankcase Splitting).
- Pull off the shift rods [A], and disengage the shift fork guide pins from the shift drum grooves.
- Remove the shift drum [B]
- Remove the shift forks [C] from the transmission gears.
- Take out the drive shaft [D] and output shaft [E] together with their gears meshed.




### Transmission Shaft Installation

- Set the transmission shafts, shift drum, and shift forks together, and fit them into the right crankcase half.
  - Apply transmission oil liberally to the transmission gears, bearings, shaft journals, and shift fork fingers.
  - Fit each shift fork into the groove of the proper gear so that the shift fork guide pin is in the proper groove on the shift drum.
- [A] Shorter Shift Fork (Drive Shaft)  
 [B] Left Shift Fork (Output Shaft)  
 [C] Longer Shift Rod (Output Shaft)  
 [D] Shift Drum  
 [E] Shorter Shift Rod (Drive Shaft)  
 [F] Right Shift Fork (Output Shaft)
- Apply small amount of engine oil to the shift rods, and install the rods.

**Torque - Output Shaft Bearing Retaining Screws: 5.4 N·m (0.55 kgf·m, 48 in·lb)**

**Drive Shaft Bearing Retaining Bolts: 8.8 N·m (0.90 kgf·m, 78 in·lb)**



### NOTE

○ Be careful not to confuse the shift forks, or the shift rods.

- Assemble the crankcase (see Crankcase Assembly).

### Transmission Shaft Disassembly

- Remove the transmission shafts (see Transmission Shaft Removal).
- Using the outside circlip pliers, remove the circlips and disassemble the transmission shafts completely.

**Special Tools - Outside Circlip Pliers: 57001-144**


### Transmission Shaft Assembly

- Apply engine oil liberally to the transmission shaft, gears and bearings.
- Install a new circlip on the drive shaft so that opening coincides with one of the spline grooves in the shaft.
- Be careful not to install the gears backwards.
- The 2nd drive gear shall be installed so that the circle of identification groove face to outward (KX85-A1 ~ A4/B1 ~ B4, KX100-D1 ~ D4).
- ★ If the first gear on the output shaft is a new one, apply molybdenum disulfide grease to the internal diameter.


## 7-14 ENGINE BOTTOM END/TRANSMISSION

### Transmission

#### KX85-A1/B1, KX100-D1




#### KX85-A2 ~/B2 ~, KX100-D2 ~



#### Shift Fork Bending Inspection

- Visually inspect the shift forks, and replace any fork that is bent. A bent fork could cause difficulty in shifting, or allow the transmission to jump out of gear when under power.  
[A] 90°



## Transmission

### Shift Fork/Gear Groove Wear Installation

- Measure the thickness of the shift fork ears [A], and measure the width of the shift fork grooves [B] in the transmission gears.
- ★ If the thickness of a shift fork finger is less than the service limit, the shift fork must be replaced.

#### Shift Fork Finger Thickness

**Standard:** 3.9 ~ 4.0 mm (0.154 ~ 0.157 in.)


**Service Limit:** 3.8 mm (0.150 in.)

- ★ If a gear shift fork groove is worn over the service limit, the gear must be replaced.

#### Gear Shift Fork Groove Width

**Standard:** 4.05 ~ 4.15 mm (0.159 ~ 0.163 in.)

**Service Limit:** 4.3 mm (0.169 in.)



### Shift Fork Guide Pin/Shift Drum Groove Wear Inspection


- Measure the diameter of each shift fork guide pin [A], and measure the width of each shift drum groove [B].
- ★ If the guide pin on any shift fork is less than the service limit, the fork must be replaced.

#### Shift Fork Guide Pin Diameter

**Standard:** 5.9 ~ 6.0 mm (0.232 ~ 0.236 in.)

**Service Limit:** 5.8 mm (0.228 in.)

- ★ If any shift drum groove is worn over the service limit, the drum must be replaced.



6113004BS1 C


#### Shift Drum Groove Width

**Standard:** 6.05 ~ 6.20 mm (0.238 ~ 0.244 in.)

**Service Limit:** 6.3 mm (0.248 in.)

### Gear Dog/Gear Dog Hole Damage Inspection


- Visually inspect the gear dogs [A] and gear dog holes [B].
- ★ Replace any damaged gears or gears with excessively worn dogs or dog holes.



6113014BS1 C

### Ball Bearing Wear Inspection

- Check the ball bearing on the crankcase.
- Since the ball bearings are made to extremely close tolerances, the wear must be judged by feel rather than measurement.
- Oil the bearing with transmission oil and spin [A] it by hand to check its condition.
- ★ If the bearing is noisy, does not spin smoothly, or has any rough spots, replace it.



6113014BS1 C






# Wheels/Tires

## Table of Contents

|  |      |
|--|------|
| Exploded View .....                      | 8-2  |
| Specifications .....                     | 8-3  |
| Wheels (Rims) .....                      | 8-5  |
| Front Wheel Removal .....                | 8-5  |
| Front Wheel Installation .....           | 8-5  |
| Rear Wheel Removal .....                 | 8-5  |
| Rear Wheel Installation .....            | 8-6  |
| Wheels Inspection .....                  | 8-7  |
| Spoke Inspection .....                   | 8-7  |
| Rim Inspection .....                     | 8-7  |
| Axle Inspection .....                    | 8-7  |
| Tires .....                              | 8-8  |
| Removal .....                            | 8-8  |
| Installation .....                       | 8-9  |
| Air Pressure Inspection/Adjustment ..... | 8-9  |
| Inspection .....                         | 8-10 |
| Hub Bearing (Wheel Bearings) .....       | 8-11 |
| Removal .....                            | 8-11 |
| Installation .....                       | 8-11 |
| Inspection .....                         | 8-11 |
| Lubrication .....                        | 8-11 |

## 8-2 WHEELS/TIRES

### Exploded View



T1: 79 N·m (8.1 kgf·m, 58 ft·lb)

T2: 1.5 ~ 3.0 N·m (0.15 ~ 0.31 kgf·m, 13 ~ 27 in·lb)

G: Apply grease.

WL: Apply soap and water solution, or rubber lubricant.