



A-1 E6:01, E6:02, E6:03, and E6:04 are displayed at the same time

- ★ Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on the next step.
- ★ The error code displayed on the HYPER monitor or GX panel does not go out until the starting switch is turned OFF.



A-1 Related electric circuit diagram



TKP00840

020Y06