


## ASSEMBLY OF DIFFERENTIAL

- ★ Coat the rotating surfaces of the bearing roller, inner race and outer race rollers with engine oil before installing.

1. Using the eyebolts (Dia. = 24 mm, Pitch = 3.0 mm), install the bevel gear.




 Mounting bolt: **Adhesive (LT-2)**

 Mounting bolt: **932 ± 98 Nm {95 ± 10 kgm}**



2. Install thrust washer (31).
  - ★ Align the thrust washer with the dowel pin when installing.

3. Install bevel gear (30).


- ★ Assemble pinion gear as follows.
  - 1) Install outer races (29) and (28).



- 2) Press fit bearing (27) in shaft.




- 3) Assemble collar (26).





- 4) Assemble pinion gear (24) and bearing (25) in shaft.
- 5) Fit lock plate and tighten lock nut (22) with wrench ②.

★ Bend the lock plate securely.

 Lock nut:

**981 ± 98 Nm {100 ± 10 kgm}**




★ Assemble differential gear case assembly as follows.

- 1) Assemble pinion gear assembly (20) in cross shaft (21), and install to case.
  - ★ Align the notch in the pinion gear with the cross shaft dowel pin when installing.
- 2) Install bevel gear (19).

★ Move the bevel gear and check that the pinion gear assembly rotates smoothly.




- 3) Install thrust and bearing to case.
  - ★ Align the thrust with the dowel pin when installing.

- 4) Install case, and tighten mounting bolts.

 Mounting bolt: **Adhesive (LT-2)**

 Mounting bolt:

**932 ± 98 Nm {95 ± 10 kgm}**



4. Tighten nut (12) temporarily, and put differential gear case assembly (15) in differential case.
  - ★ Align the nut with the groove in the differential case, then check that it rotates smoothly by hand.

