




3. Take out the plug (5) then remove the push rod (6) from the plug (5).
 - If the plug is difficult to remove, use (-) screw driver to remove it.
 - Be careful not to let the plug fly out from the spring's force.




4. Remove the O-ring (7) and seal (8) from the plug.




5. Remove the reducing valve (12) and spring (13).
 - Make match marks on the reducing valve and casing hole so they can be placed in the same position when they are reassembled.



6. Disassemble the reducing valve.
 - a. Push in the spring sheet (14) to contract the spring (15), and move the spool (17) from the small hole to the large hole of the spring sheet (14).
 - Do not push in the spring sheet too far (at most 6 mm).




- b. Remove the spring seat (14), spring (15) and washer 2 (16) from the spool (17).



YI-D310


Assembly

1. Assemble the reducing valve (12).
 - a. Install the washer 2 (16), spring (15) and spring seat (14) on the spool (17).




YI-D310

- b. Push in the spring sheet (14) to contract the spring (15), and move the spool (17) from the large hole to the small hole of the spring sheet (14).
 - Do not push in the spring sheet too far (at most 6 mm).




N0D3061



2. Install the spring (13) and reducing valve (12).
 - Install them in the positions they were in before disassembly.



3. Install the O-ring (7) and seal (8) in the plug (5).




4. Install the push rod (9) in the plug (5).
 - Apply hydraulic oil to the push rod.




5. Install the plug (5) and plate (4), then install the joint.
 - Use installation jigs (A) and (B) to install the joint.

⊞ Joint: $47.1 \pm 2.9 \text{ N}\cdot\text{m}$




6. Install the disc (2), the adjust nut (1) and the lock nut.
 - Tighten the adjust nut to the point where all 4 push rods are uniformly making contact.
 - During tightening, the disc should not be moved.

🔧 Adjust Nut: $68.6 \pm 4.9 \text{ N}\cdot\text{m}$




7. Apply grease to the contact surfaces of the joint rotating portion, the disc and the push rod.



INSPECTION AND ADJUSTMENT

Checking the Parts

Parts	Judgment Criteria	Treatment
O-ring	—	• Replace
Seal	—	• Replace
Spool	<ul style="list-style-type: none"> • Wear on sliding portions is 10 μm or greater compared to non-sliding portions • Scratches on sliding portions • Spool doesn't move smoothly 	<ul style="list-style-type: none"> • Replace • Replace • Repair or replace
Push Rod	<ul style="list-style-type: none"> • Front end is worn 1 mm or more 	<ul style="list-style-type: none"> • Replace
Plug	<ul style="list-style-type: none"> • Seal is imperfect due to damage 	<ul style="list-style-type: none"> • Repair or replace
Operating Portion	<ul style="list-style-type: none"> • Tightening is loose at the pin, shaft or joint of the operating portion, with looseness of 2 mm or greater • Due to wear, etc. tightening is loose at the pin, shaft or joint of the operating portion, with looseness of 2 mm or greater 	<ul style="list-style-type: none"> • Tighten to the specified torque • Replace
Casing, Port Plate	<ul style="list-style-type: none"> • Scratches, rust or corrosion on the spool and sliding portion • Scratches, rust or corrosion on seal portions which come in contact with the O-ring 	<ul style="list-style-type: none"> • Replace • Repair or replace

TROUBLESHOOTING

Symptom	Probable Causes	Remedy
Secondary pressure doesn't rise	<ul style="list-style-type: none"> • Primary pressure is insufficient • Spring is damaged or permanently deformed • The clearance between the spool and casing is abnormally large • There is looseness in the handle 	<ul style="list-style-type: none"> • Keep the primary pressure • Replace the spring • Replace the spool and casing assembly • Disassemble and reassemble, or replace the handle
Secondary pressure doesn't stabilize	<ul style="list-style-type: none"> • Sliding parts are catching • Tank line pressure fluctuates • Air gets mixed into the piping 	<ul style="list-style-type: none"> • Repair or replace • Remove the abnormal portions of the tank line • Operate the machine several times and bleed out the air
Secondary pressure is high	<ul style="list-style-type: none"> • Tank line pressure is high • Sliding parts are catching 	<ul style="list-style-type: none"> • Remove the abnormal portions of the tank line • Repair or replace

