

## Refitting the valves

- Lubricate the valve guides with graphite grease.
- Place the lower caps of the valve spring on the head.
- Use the punch to fit the 4 sealing rings one at a time.



- Fit the valves, the springs and the upper caps.
- Using the appropriate tool, compress the springs and insert the cotters in their seats.



## Inspecting the cam shaft

- Inspect the camshaft for signs of abnormal wear on the cams.

### Characteristic

#### Standard diameter - Bearing A:

$\varnothing 12 +0.002 +0.010$

#### mm Standard diameter - Bearing B:

$\varnothing 16-0.015 -0.023$  mm

#### Minimum diameter allowed - Bearing A:


$\varnothing 11.98$  mm

#### Minimum diameter allowed - Bearing B:

$\varnothing 15.96$  mm

- Using a gauge, measure the cam height.


Check the axial clearance of the camshaft



- If any of the above dimensions are outside the specified limits, or there are signs of excessive wear, replace the defective components with new ones.

**N.B.**

**A BALL BEARING IS FITTED ON BEARING «A»; CONSEQUENTLY, BEARING «B» IS THE MOST IMPORTANT AS IT WORKS DIRECTLY ON THE HEAD ALUMINIUM**



**Characteristic**

**Standard height - Inlet**


24.397 mm

**Standard height - Outlet**

23.996 mm

**Fitting clearance**

**Maximum admissible axial clearance:** 0.5 mm



- Measure the outside diameter of the rocking lever pins
- Check the rocking lever pins do not show signs of wear or scoring.
- Measure the internal diameter of each rocking lever.
- Check that the pad in contact with the cam is not worn.

**ROCKING LEVERS AND PIN DIAMETER:**

Specification	Desc./Quantity
Rocking levers - Inside diameter	11.015 ÷ 11.035 mm
Rocking levers - Pins diameter	10.977 ÷ 10.985 mm



**Refitting the head and timing system components**

- Fix the head on a workbench.
- Screw the tool to fit the camshaft fully down on the bearing's inner track.
- Fit the camshaft fully into its seating together with the bearing with the aid of a mallet.
- Remove the tool.
- Fit the head gasket after cleaning the faying surface carefully.

- Insert the head in the cylinder stud bolts and tighten the 4 fixing nuts to the prescribed torque.

## Specific tooling

### 020450Y Camshaft fitting/removal tool

- Fit pins, inlet rocking lever and discharge rocking lever.

- Lubricate the 2 rocking levers through the holes.

**N.B.**

**IF A BEARING SEPARATES FROM THE CAMSHAFT, IT IS ESSENTIAL TO FIT A NEW BEARING.**




- Screw up the limit screw of the rocking lever pins and tighten it to the prescribed torque.

- Reposition the Seeger ring retaining the camshaft

## Locking torques (N\*m)

**Rocking lever shafts screw 3 ÷ 4**



- Finish the head tightening following the procedure below: screw the four head nuts to an initial torque at two crossed passes. Afterwards tighten the nuts with 2 turns of 90° each to be done at two crossed passes.


- Finish the tightening of the head to the crankcase with the 2 side screws.

**N.B.**

**SHOULD THE CRANKCASE OR THE CYLINDER STUD BOLTS BE REPLACED, IT IS NECESSARY TO CARRY OUT AN INITIAL TIGHTENING PLUS OTHER 3 TURNS OF 90° EACH AT 3 CROSSED PASSES**


## Locking torques (N\*m)

**Head-cylinder stud bolt nuts: 6 to 7 +135° +90° Nm**  
**first fitting, upon refitting tighten again at 6 to 7 90° +90° Nm**  
**Head cover screws 8 to 10 Nm**



## Refitting the timing chain


- Insert the timing chain pads in their corresponding seatings, the screw and the spacer as indicated in the figure.
- Tighten to the prescribed torque and check the tensioner pad moves adequately.
- Insert the timing pinion in driving shaft with the chamfered side facing the insertion (towards the main bearing).
- Loop the timing chain around the sprocket on the crankshaft.




### Locking torques (N\*m)

#### Chain tensioner pad screw 5 to 7 Nm

- Refit the spacer on the cam shaft.
- Rotate the engine so that the piston is at top dead centre, using the reference marks on the flywheel and the crankcase.
- With this operation, insert the chain on the camshaft control pulley and make the reference notch coincide with the point on the head.
- Fit the pulley onto the camshaft.
- Fit the belleville washer so that the outer rim touches the pulley.
- Bring the screw closer but without reaching its final locking point.



- Push the tensioner pad lightly so as to check the correct timing.
- Use the specific tool to lock the camshaft crown gear and tighten the screw.
- Adjust valve clearance.
- Replace the O-ring on the tappet cover.
- Fit the tappet cover and lock it with the 4 fixing screws indicated in the figure.



### Specific tooling

#### 020565Y Flywheel lock calliper spanner

### Locking torques (N\*m)

**Camshaft pulley screw 12 to 14 Head cover screw 8 to 10 Nm**

- Set the tensioner cursor in the rest position.
- Fit the chain tensioner on the cylinder, using a new gasket, and tight the two screws to the prescribed torque.
- Insert the spring with the central screw and tighten it to the prescribed torque.
- Fit the spark plug.

**Characteristic****Electrode gap**

0.5 ÷ 0.6 mm

**Electric characteristic****Spark plug**

NGK ER9EH-6N

**Locking torques (N\*m)**


Timing chain tensioner central screw 5 to 6 Timing chain tensioner screw 8 to 10 Nm Ignition spark plug 10 to 15 Nm

**Refitting the rocker-arms cover**


- Carry out the removal procedure but in reverse order and tighten the four fixing screws to the specified torque.

**N.B.**

**FIT A NEW O-RING ON THE TAPPET COVER.**

**Refitting the intake manifold**


- Fit the cover sealing gaskets on the head.
- Fit the 2 covers.
- Fit the inlet manifold and do up the 2 screws to the specified torque.
- Fit the carburettor on the inlet manifold and lock the clamp.
- Fit the secondary air pipe and fix it with the appropriate clamp.

**N.B.**

- Check the axial clearance on the connecting rod.

### Fitting clearance


**Standard connecting rod axial clearance 0.15 to 0.30 mm Max. connecting rod clearance 0.5 mm**



- Check the correct radial clearance of the connecting rod by holding the driving shaft with your hands and, with a dial gauge fitted to the rod small end, measuring the clearance, move the connecting rod vertically as shown in the figure.

### Fitting clearance

**Connecting rod radial - standard clearance 0.006 to 0.018 mm Connecting rod max. - radial clearance 0.25 mm**




- Check that the half shaft surfaces are not scored and with the aid of a gauge check the driving shaft width as indicated in the figure.

### Characteristic

**Standard measure**

45 mm



## Removing the crankshaft bearings

- Remove the flywheel bearing fitted on the driving shaft using the specific tool.

### Specific tooling


**004499Y Camshaft bearing extractor**

**004499Y001 Bearing extractor bell**

**004499Y002 Bearing extractor screw**


**004499Y006 Bearing extractor ring**

**004499Y034 Bearing extractor part**



## Refitting the crankshaft bearings

- Support the crankcase on a surface and place it with the driving shaft axle in a vertical position.
- Warm the crankcase at ~ 120° C with a thermal gun (and support).
- Fit the punch with guide and adaptor, place the bearing on the punch using grease (to keep it from falling).
- Insert the bearing in the crankcase; if needed, use a mallet but do so with extreme care so as not to damage the engine crankcase limit stop.



### Specific tooling

**020359Y 42x47-mm Adaptor**

**020364Y 25-mm guide**

**020376Y Adaptor handle**

**020360Y 52x55-mm Adaptor**


- Heat a new main bearing in an oil bath at 120°.
- Place the driving shaft on the support base and insert the bearing with the aid of an adequate piece of tube if necessary.

**N.B.**

**USE A NEW BEARING WHEN REFITTING**

**WARNING**

**THE CENTRIFUGAL OIL FILTER IS IN THE FLYWHEEL AXLE SHAFT. DO NOT WASH WITH SOLVENTS OR BLOW COMPRESSED AIR SO THAT NO IMPURITIES LEAK OUT.**



### Specific tooling

**020265Y Bearing fitting base**

**008119Y009 Tube to assemble shafts and axles**