





EAS00311



CLUTCH RELEASE CYLINDER



Order	Job/Part	Q'ty	Remarks
	<b>Removing the clutch release cylinder</b>		Remove the parts in the order listed.
1	Bolt	3	Refer to "INSTALLING THE CLUTCH RELEASE CYLINDER". <b>NOTE:</b> _____ Before removing the clutch release cylinder, drain the clutch fluid from the entire clutch system.
2	Union bolt	1	Refer to "INSTALLING THE CLUTCH RELEASE CYLINDER".
3	Copper washer	3	
4	Spacer	1	
5	Clutch hose	1	
6	Clutch release cylinder	1	
			For installation, reverse the removal procedure.



Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the clutch release cylinder</b>		Disassembly the parts in the order listed.
①	Clutch release cylinder	1	Refer to "DISASSEMBLING THE CLUTCH RELEASE CYLINDER".
②	Piston seal	1	
③	Clutch release cylinder piston	1	
④	Piston seal	1	
⑤	Spring	1	
			For assembly, reverse the disassembly procedure.



EAS00313

**DISASSEMBLING THE CLUTCH RELEASE CYLINDER**

1. Remove:
- piston seal ①
  - clutch release cylinder piston ②
  - spring ③
  - piston seal ④



- a. Blow compressed air into the clutch hose joint opening (a) to force out the piston from the clutch release cylinder.

**⚠ WARNING**


- Cover the clutch release cylinder with a rag. Be careful not to get injured when the piston is expelled from the clutch release cylinder.
- Never try to pry out the clutch release cylinder piston.

- b. Remove the clutch release cylinder piston seals.




EAS00314

**CHECKING THE CLUTCH RELEASE CYLINDER**



Recommended clutch component replacement schedule	
Piston seals	Every two years
Clutch hose	Every two years
Clutch fluid	Every two years and whenever the clutch is disassembled

1. Check:
- clutch release cylinder body  
Cracks/damage → Replace the clutch release cylinder.
2. Check:
- clutch release cylinder ①
  - clutch release cylinder piston ②  
Rust/scratches/wear → Replace the clutch release cylinder and clutch release cylinder piston as a set.



EAS00315

### INSTALLING THE CLUTCH RELEASE CYLINDER

#### 1. Check:

- copper washers (New)
- clutch hose ①
- union bolt ②

#### **⚠ WARNING**

Proper clutch hose routing is essential to insure safe motorcycle operation. Refer to "CABLE ROUTING".



**Union bolt**  
30 Nm (3.0 m•kg)

#### 2. Fill:

- clutch master cylinder reservoir (with the specified amount of the recommended clutch fluid)



**Recommended clutch fluid**  
Brake fluid DOT 4

#### **⚠ WARNING**


- Use only the designated clutch fluid. Other clutch fluids may cause the rubber seals to deteriorate, causing leakage and poor clutch performance.
- Refill with the same type of clutch fluid that is already in the system. Mixing clutch fluids may result in a harmful chemical reaction, leading to poor clutch performance.
- When refilling, be careful that water does not enter the reservoir. Water will significantly lower the boiling point of the clutch fluid and could cause vapor lock.

#### **CAUTION:**

Clutch fluid may damage painted surfaces or plastic parts. Therefore, always clean up any spilt clutch fluid immediately.

**NOTE:**

In order to ensure a correct reading of the clutch fluid level, make sure that the top of the reservoir is horizontal.



## 3. Bleed:

- clutch system

Refer to "BLEEDING THE HYDRAULIC CLUTCH SYSTEM" in chapter 3.

## 4. Check:

- clutch fluid level

Below the minimum level mark (a) → Add the recommended clutch fluid to the proper level.

Refer to "CHECKING THE CLUTCH FLUID LEVEL" in chapter 3.

## 5. Check:


- clutch lever operation

Soft or spongy feeling → Bleed the clutch system.


Refer to "BLEEDING THE HYDRAULIC CLUTCH SYSTEM" in chapter 3.





OIL PUMP



Order	Job/Part	Q'ty	Remarks
	<b>Removing the oil pump.</b>		
	Clutch		Remove the parts in the order listed. Refer to "INSTALLING THE CLUTCH".
1	Oil pump drive gear	1	
2	Collar	1	
3	Washer	1	
4	Oil buffer plate	1	
5	Circlip	1	
6	Oil pump driven gear	1	
7	Washer	1	
8	Oil pump	1	Refer to "INSTALLING THE OIL PUMP".
9	Dowel pin	1	
10	Collar	1	
11	O-ring	3	
			For installation, reverse the removal procedure.



Order	Job/Part	Q'ty	Remarks
	<b>Disassembling the oil pump</b>		Disassembly the parts in the order listed.
①	Oil pump housing	1	Refer to "ASSEMBLING THE OIL PUMP".
②	Inner rotor	1	
③	Outer rotor	1	
④	Pin	1	
⑤	Dowel pin	1	
⑥	Oil pump housing	1	
⑦	Inner rotor	1	
⑧	Outer rotor	1	
⑨	Pin	1	
⑩	Oil pump shaft	1	
⑪	Oil pump cover	1	
			For assembly, reverse the disassembly procedure.



EAS00364

## CHECKING THE OIL PUMP

### 1. Check:

- oil pump drive gear ①
  - oil pump driven gear ②
  - oil pump housing ③
  - oil pump housing cover ④
- Cracks/damage/wear → Replace the defective part(-s).

### 2. Measure:

- inner-rotor to outer-rotor tip clearance **A**
  - outer-rotor to oil-pump-housing clearance **B**
  - oil-pump-housing to inner-rotor and outer-rotor clearance **C**
- Outer of specification → Replace the oil pump.

- ① Inner rotor
- ② Outer rotor
- ③ Oil pump housing



#### Inner-rotor to outer-rotor tip clearance

0.12 ~ 0.17 mm <Limit 0.2 mm>

#### Outer-rotor to oil-pump-housing clearance

0.03 ~ 0.08 mm <Limit 0.15 mm>

#### Oil-pump-housing to inner-rotor and outer-rotor clearance

0.03 ~ 0.08 mm <Limit 0.15 mm>

### 3. Check:

- oil pump operation
- Unsmooth → Repeat steps (1) and (2) or replace the defective part(-s).