


EAS26980

CHECKING THE INJECTORS


1. Check:
 - Injectors
Damage → Replace.



EAS26990

CHECKING THE THROTTLE BODIES

1. Check:
 - Throttle bodies
Cracks/damage → Replace the throttle bodies as a set.
 2. Check:
 - Fuel passages
Obstructions → Clean.



- c. Connect the pressure gauge "2" and adapter "3" to the fuel hose (fuel tank to primary injector fuel rail).

Pressure gauge


90890-03153

YU-03153


Fuel pressure adapter

90890-03176

YM-03176



- d. Start the engine.
 - e. Measure the fuel pressure.



Fuel pressure
324 kPa (46.1 psi) (3.24 kg/cm²)

Faulty → Replace fuel pump.

FWA4C81001




Cover fuel hose connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the hoses.

EAS27030

ADJUSTING THE THROTTLE POSITION SENSOR (FOR THROTTLE VALVES)

1. Check:
 - Throttle position sensor (for throttle valves)
Refer to "CHECKING THE THROTTLE POSITION SENSOR (FOR THROTTLE VALVES)" on page 8-89.
 2. Adjust:
 - Throttle position sensor angle


- a. Temporary tighten the throttle position sensor (for throttle valves).
 - b. Check that the throttle valves are fully closed.
 - c. Connect the throttle position sensor (for throttle valves), throttle position sensor (for throttle cable pulley) and throttle servo motor to the wire harness.
 - d. Turn the main switch to "OFF" and set the engine stop switch to "ON".
 - e. Simultaneously press and hold the "SELECT" and "RESET" buttons, turn the main switch to "ON", and continue to press the buttons for 8 seconds more.



NOTE:-

“dIAG” appears on the odometer, tripmeter and fuel reserve trip LCD.

- f. Diagnostic code 01 is selected.
 - g. Adjust the position of the throttle position sensor angle so that 16 can appear in the meter.
 - h. After adjusting the throttle position sensor angle, tighten the throttle position sensor screws “1”.




EAS4C81023

ADJUSTING THE THROTTLE POSITION SENSOR (FOR THROTTLE CABLE PUL- LEY)

1. Check:
 - Throttle position sensor (for throttle cable pulley)
Refer to "ADJUSTING THE THROTTLE POSITION SENSOR (FOR THROTTLE CABLE PULLEY)" on page 7-7.
 2. Adjust:
 - Throttle position sensor (for throttle cable pulley) angle

- a. Temporary tighten the throttle position sensor (for throttle cable pulley).
- b. Check that the throttle valves are fully closed.
- c. Connect the throttle position sensor (for throttle valves), throttle position sensor (for throttle cable pulley) and throttle servo motor to the wire harness.
- d. Turn the main switch to "OFF" and set the engine stop switch to "ON".
- e. Simultaneously press and hold the "SELECT" and "RESET" buttons, turn the main switch to "ON", and continue to press the buttons for 8 seconds more.
Simultaneously press and hold the "SELECT" and "RESET" buttons, turn the main switch to "ON", and continue to press the buttons for 8 seconds more.




NOTE:-

“dIAG” appears on the odometer, tripmeter and fuel reserve trip LCD.

- f. Diagnostic code 14 is selected.
 - g. Adjust the position of the throttle position sensor angle so that 17 can appear in the meter.
 - h. After adjusting the throttle position sensor angle, tighten the throttle position sensor screws “1”.

THROTTLE BODIES




▲▲▲▲▲▲▲▲▲▲▲▲▲▲▲▲▲▲▲▲▲

EAS27040

AIR INDUCTION SYSTEM

Removing the air cut-off valve assembly and hoses



Order	Job/Parts to remove	Q'ty	Remarks
1	Air cut-off valve coupler	1	Disconnect.
2	Air cut-off valve hose 1	1	Disconnect.
3	Air cut-off valve hose 2	1	Disconnect.
4	Air cut-off valve hose 3	1	Disconnect.
5	Air cut-off valve	1	
6	Reed valve cap	2	
7	Reed valve assembly	2	
8	Plate	4	
			For installation, reverse the removal procedure.



EAS27060

CHECKING THE AIR INDUCTION SYSTEM**Air injection**

The air induction system burns unburned exhaust gases by injecting fresh air (secondary air) into the exhaust port, reducing the emission of hydrocarbons. When there is negative pressure at the exhaust port, the reed valve opens, allowing secondary air to flow into the exhaust port. The required temperature for burning the unburned exhaust gases is approximately 600 to 700°C.

Air cut-off valve

The air cut-off valve is controlled by the signals from the ECU in accordance with the combustion conditions. Ordinarily, the air cut-off valve opens to allow the air to flow during idle and closes to cut-off the flow when the vehicle is being driven. However, if the coolant temperature is below the specified value, the air cut-off valve remains open and allows the air to flow into the exhaust pipe until the temperature becomes higher than the specified value.



- A. From the air cleaner
- B. To the cylinder head


1. Check:

- Hoses
Loose connections → Connect properly.
Cracks/damage → Replace.

- Pipes
Cracks/damage → Replace.

2. Check:

- Reed valve "1"
- Reed valve stopper
- Reed valve seat
Cracks/damage → Replace the reed valve.




3. Measure:

- Reed valve bending limit "a"
Out of specification → Replace the reed valve.



**Reed valve bending limit
0.4 mm (0.016 in)**



I4710301

4. Check:

- Air cut-off valve
Cracks/damage → Replace.

5. Check

- Air induction system solenoid
Refer to "CHECKING THE AIR INDUCTION SYSTEM SOLENOID" on page 8-90.

AIR INDUCTION SYSTEM

ELECTRICAL SYSTEM

IGNITION SYSTEM.....	8-1
CIRCUIT DIAGRAM.....	8-1
TROUBLESHOOTING	8-3
ELECTRIC STARTING SYSTEM.....	8-5
CIRCUIT DIAGRAM.....	8-5
STARTING CIRCUIT CUT-OFF SYSTEM OPERATION.....	8-7
TROUBLESHOOTING	8-9
CHARGING SYSTEM	8-11
CIRCUIT DIAGRAM.....	8-11
TROUBLESHOOTING	8-13
LIGHTING SYSTEM	8-15
CIRCUIT DIAGRAM.....	8-15
TROUBLESHOOTING	8-17
SIGNALING SYSTEM.....	8-19
CIRCUIT DIAGRAM.....	8-19
TROUBLESHOOTING	8-21
COOLING SYSTEM.....	8-25
CIRCUIT DIAGRAM.....	8-25
TROUBLESHOOTING	8-27
FUEL INJECTION SYSTEM.....	8-29
CIRCUIT DIAGRAM.....	8-29
ECU SELF-DIAGNOSTIC FUNCTION	8-31
FAIL-SAFE ACTIONS	
(SUBSTITUTE CHARACTERISTICS OPERATION CONTROL)	8-32
TROUBLESHOOTING METHOD	8-35
DIAGNOSTIC MODE.....	8-36
TROUBLESHOOTING DETAILS	8-44
FUEL PUMP SYSTEM.....	8-65
CIRCUIT DIAGRAM.....	8-65
TROUBLESHOOTING	8-67
ELECTRICAL COMPONENTS.....	8-69
CHECKING THE SWITCHES.....	8-73
CHECKING THE BULBS AND BULB SOCKETS.....	8-76
CHECKING THE FUSES.....	8-77
CHECKING AND CHARGING THE BATTERY.....	8-77
CHECKING THE RELAYS.....	8-80
CHECKING THE TURN SIGNAL RELAY	8-81
CHECKING THE RELAY UNIT (DIODE)	8-82

CHECKING THE IGNITION COILS	8-83
CHECKING THE CRANKSHAFT POSITION SENSOR.....	8-84
CHECKING THE LEAN ANGLE SENSOR.....	8-84
CHECKING THE STARTER MOTOR OPERATION.....	8-85
CHECKING THE STATOR COIL.....	8-85
CHECKING THE RECTIFIER/REGULATOR.....	8-85
CHECKING THE HORN	8-86
CHECKING THE OIL LEVEL SWITCH	8-86
CHECKING THE FUEL SENDER	8-87
CHECKING THE SPEED SENSOR	8-87
CHECKING THE RADIATOR FAN MOTORS	8-88
CHECKING THE COOLANT TEMPERATURE SENSOR	8-88
CHECKING THE THROTTLE POSITION SENSOR (FOR THROTTLE CABLE PULLEY).....	8-89
CHECKING THE THROTTLE POSITION SENSOR (FOR THROTTLE VALVES).....	8-89
CHECKING THE AIR INDUCTION SYSTEM SOLENOID	8-90
CHECKING THE ATMOSPHERIC PRESSURE SENSOR.....	8-90
CHECKING THE CYLINDER IDENTIFICATION SENSOR	8-91
CHECKING THE INTAKE AIR PRESSURE SENSOR	8-91
CHECKING THE INTAKE AIR TEMPERATURE SENSOR	8-91


IGNITION SYSTEM

EAS27090

IGNITION SYSTEM

EAS27110

CIRCUIT DIAGRAM



1. Main switch
4. Main fuse
7. Battery
11. Starting circuit cut-off relay
12. Neutral switch
13. Side stand switch
18. ECU (engine control unit)
19. Ignition coil #1
20. Ignition coil #2
21. Ignition coil #3
22. Ignition coil #4
23. Spark plug
34. Crankshaft position sensor
39. Lean angle sensor
56. Engine stop switch
62. Clutch switch
77. Ignition fuse
85. Ground
86. Battery negative lead

EAS27150


TROUBLESHOOTING

The ignition system fails to operate (no spark or intermittent spark).

NOTE:

- Before troubleshooting, remove the following part(s):

- 1 Rider seat
- 2 Passenger seat
- 3 Fuel tank
- 4 Side cowlings



8 Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-73.	OK↓	NG→	Replace the right handlebar switch.
9 Check the neutral switch. Refer to "CHECKING THE SWITCHES" on page 8-73.	OK↓	NG→	Replace the neutral switch.
10 Check the sidestand switch. Refer to "CHECKING THE SWITCHES" on page 8-73.	OK↓	NG→	Replace the sidestand switch.
11 Check the clutch switch. Refer to "CHECKING THE SWITCHES" on page 8-73.	OK↓	NG→	Replace the clutch switch.
12 Check the starting circuit cut-off relay. Refer to "CHECKING THE RELAYS" on page 8-80.	OK↓	NG→	Replace the starting circuit cut-off relay.
13 Check the lean angle sensor. Refer to "CHECKING THE LEAN ANGLE SENSOR" on page 8-84.	OK↓	NG→	Replace the lean angle sensor.
14 Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-1.	OK↓	NG→	Properly connect or repair the ignition system's wiring
Replace the ECU.			


ELECTRIC STARTING SYSTEM

EAS27160

ELECTRIC STARTING SYSTEM

EAS27170

CIRCUIT DIAGRAM



ELECTRIC STARTING SYSTEM

1. Main switch
4. Main fuse
7. Battery
9. Starter relay
10. Starter motor
11. Starting circuit cut-off relay
12. Neutral switch
13. Side stand switch
56. Engine stop switch
57. Start switch
62. Clutch switch
77. Ignition fuse
85. Ground
86. Battery negative lead

ELECTRIC STARTING SYSTEM


EAS27180

STARTING CIRCUIT CUT-OFF SYSTEM OPERATION

If the engine stop switch is set to “” and the main switch is set to “ON” (both switches are closed), the starter motor can only operate if at least one of the following conditions is met:

- The transmission is in neutral (the neutral switch is closed).
 - The clutch lever is pulled to the handlebar (the clutch switch is closed) and the sidestand is up (the sidestand switch is closed).

The starting circuit cut-off relay prevents the starter motor from operating when neither of these conditions has been met. In this instance, the starting circuit cut-off relay is open so current cannot reach the starter motor. When at least one of the above conditions has been met the starting circuit cut-off relay is closed and the engine can be started by pressing the starter switch.



ELECTRIC STARTING SYSTEM

- a. WHEN THE TRANSMISSION IS IN NEUTRAL
 - b. WHEN THE SIDESTAND IS UP AND THE CLUTCH LEVER IS PULLED TO THE HANDLEBAR
1. Battery
 2. Main fuse
 3. Main switch
 4. Ignition fuse
 5. Engine stop switch
 6. Starting circuit cut-off relay
 7. Diode
 8. Clutch switch
 9. Sidestand switch
 10. Neutral switch
 11. Start switch
 12. Starter relay
 13. Starter motor
 14. Battery negative lead
 15. Ground

EAS27190


TROUBLESHOOTING

The starter motor fails to turn.


NOTE:

- Before troubleshooting, remove the following part(s):

- 1 Rider seat
- 2 Passenger seat
- 3 Fuel tank
- 4 Air filter case




ELECTRIC STARTING SYSTEM



EAS27200

CHARGING SYSTEM

EAS27210

CIRCUIT DIAGRAM

CHARGING SYSTEM

- 2. AC magneto
- 3. Rectifier/regulator
- 4. Main fuse
- 7. Battery
- 85. Ground
- 92. Battery negative lead

EAS27230

TROUBLESHOOTING

The battery is not being charged.


NOTE:

- Before troubleshooting, remove the following part(s):

1 Rider seat

2 Fuel tank

3 Air filter case




CHARGING SYSTEM

EAS27240

LIGHTING SYSTEM

EAS27250

CIRCUIT DIAGRAM



1. Main switch
4. Main fuse
7. Battery
18. ECU (engine control unit)
49. High beam indicator light
52. Meter light
60. Dimmer switch
69. Headlight
70. Auxiliary light
72. License plate light
74. Tail/brake light
75. Headlight relay (on/off)
76. Headlight relay (dimmer)
79. Headlight fuse
85. Ground
86. Battery negative lead

EAS27260

TROUBLESHOOTING

Any of the following fail to light: headlight, high beam indicator light, taillight, license light or meter light.

NOTE:

- Before troubleshooting, remove the following part(s):

- 1 Rider seat
- 2 Fuel tank
- 3 Side cowlings

