



TRANSMISSION WIRING HARNESS

6001-18

25. Install the sight gauge upper hose (30) to the fitting at the top of the transmission and tighten the clamp., refer to illustration on page 19.
26. Install the filler tube (31) on the transmission.
27. Install the sight gauge lower hose (29) to the fill tube (31) and tighten the clamp.
28. Install the filter bypass hose (25).
29. Install the filter inlet hose (26).
30. Install the filter return hose (27).
31. Install the parking brake hose (not shown).
32. Install the oil cooler hoses (not shown).