


Model 166, 292

Modification notes

21.9.15	Special tool inserted	Operation step 2	
---------	-----------------------	------------------	--



P62.30-3065-09


Shown on model 166

1	Cross strut	3.1	Screw	4.2	Screw
2.1	Screw	3.2	Screw	5.1	Strut, right
2.2	Screw	4.1	Screw	5.2	Strut, left


Danger!	Risk of injury caused by scraping or cutting body parts on sharp vehicle parts	Always wear protective gloves when working on or near sharp and non-deburred vehicle parts. Deburr repair panels.	AS00.00-Z-0017-01A
	General information on body repair		AH60.00-N-0001-01A
	General information on MB materials		AH98.00-P-9409-03A
	Remove/install		
1	Open engine hood		
2	Secure cooler with fastening strap against falling down	Fastening belt Adapter for fastening belt	*211589056300 *209589006300
3	Lift vehicle on vehicle lift		AR00.60-P-1000GZ
4	Remove front section of fender liner in right and left front fender		AR88.10-P-1310GQ
5	Remove underfloor paneling		AR61.30-P-1001GQ
6	Unscrew bolts (2.1, 2.2) and remove spacers sleeves behind struts, on left and right (5.1, 5.2)	Screw/bolt, cross strut to impact absorber	*BA62.30-P-1002-02I
7	Unscrew bolts (4.1, 4.2)	Model 166 Screw/bolt, cross strut to impact absorber	*BA62.30-P-1002-02I
8	Unscrew bolts (3.1, 3.2) and remove cross strut (1)	Screw/bolt, cross strut to impact absorber	*BA62.30-P-1002-02I
9	Install in the reverse order		

Nm Frond end with reinforcement

Number	Designation		Model 166	Model 292
BA62.30-P-1002-02I	Screw/bolt, cross strut to impact absorber	Nm	25	25



Adapter for fastening belt



Fastening belt