
## Track rollers - Remove - TerraGlide™

CR10.90	WE
CR7.90	WE
CR8.80	WE
CR8.90	WE
CR9.80	WE
CR9.90	WE

1. Remove the rubber track (1), see Rubber track - Remove (48.100).


**NOTE:** It is not required to remove the rubber tracks, in order to remove an individual track roller.




ZEIL14CR00005AA

1

2. Remove the drain plug (2) and drain the oil from the track roller (3) in a suitable container.




3. Remove the retaining ring (4), the cover (5) and the O-ring (6).



ZEIL14CR00012AA 3


- 4. Remove the bolt (7) and the retainer (8).
- 5. Remove the track roller **(3)** along with the bearings from the hub.




ZEIL14CR00013AA 4

- 6. Cover the wheel hub **(9)** to avoid dirt and damage.
- 7. Remove the bolt **(10)** and the pin **(11)**. Secure the spacers of the hydraulic cylinder.
- 8. Remove the bolt (12) and the pin (13).

9. Raise the track frame (15) and pull out the track rollers assembly (16).






47869937 05/05/2015 48.1 [48.138] / 5

## Track rollers - Install - TerraGlide™


CR10.90	WE
CR7.90	WE
CR8.80	WE
CR8.90	WE
CR9.80	WE
CR9.90	WE

1. Place the track roller assembly (1) below the track frame (2) as shown.




ZEIL14CR00020AA

- 2. Align the hydraulic cylinder (3) to the hinge arm of the track roller assembly with the two spacers (4) on both sides. Secure in place with the pin (5).
- 3. Install the bolt (6) and tighten to a torque between 133 153 N⋅m (98.1 112.8 lb ft).



ZEIL14CR00031AZ 2

- 4. Align the hole on the other side of the hinge arm to the hole on the track frame and install the pin (7).
- 5. Apply LOCTITE® 242® to the bolt (8) and tighten to a torque between 70 80 N·m (51.63 59 lb ft).
- 6. Clean the shaft (9).



ZEIL14CR00014AA 3

7. Install the track roller (10) along with the bearings. Install the retainer (11) and the bolt (12).


**NOTE:** Make sure that he bearings, O-ring and track roller is clean from any dust or dirt.


- Tighten the bolt (12) to a torque between 455 510 N·m (335.6 - 376.2 lb ft).
- 9. Install the O-ring (13), the cover (14) and the circlip (15).

**NOTE:** Apply a small amount of **NEW HOLLAND AMBRA GR 75 MD** to the O-ring before installation.


- 10. Install the drain plug (16) and tighten to a torque between 4 - 4.5 N·m (2.95 - 3.32 lb ft).
- 11. Fill the track roller hub with the recommended oil, refer to the operator's manual of the machine.

47869937 05/05/2015 48.1 [48.138] / 7









- 12. Install the rubber track, refer to **Rubber track Install** - TerraGlide<sup>™</sup> (48.100).
- 13. Calibrate the tracks, refer to the operator's manual of the machine.