

# Electrical System

---

## BATTERY

### Removal and Installation

**FIG. 1:** Raise hood.



**FIG. 1**

**FIG. 2:** Remove the battery cables from the negative post first and then from the positive post.



**FIG. 2**

**FIG. 3:** Remove the battery hold down plate and remove battery.



**FIG. 3**

## INSTRUMENT PANEL

### Removal and Installation

**FIG. 4:** To remove instrument panel proceed as follows:

Disconnect cable from negative post on battery.

Remove Philips screws and remove steering column cover.

Remove Philips screws which hold instrument panel and raise panel a small amount.

Remove nut on front of start switch and remove switch from instrument panel.




**FIG. 4**

**FIG. 5:** Remove wiring connections.

Remove instrument panel.

Reverse procedures to install instrument panel.




**FIG. 5**

## FUEL GAUGE SENSOR INSPECTION

### Removal and Installation

**FIG. 6:** Disconnect cable from negative post on battery. Remove philips screws and lift panel a small amount. Remove wiring and remove fuel gauge. Remove screws and remove fuel tank sensor.



**FIG. 6**