INDEX

CX20B CX22B CX27B

| | Title | Index No. |
|-----------------|---|-----------|
| SPECIFICATIONS | OUTLINE | 1 |
| | SPECIFICATIONS | 2 |
| | ATTACHMENT DIMENSIONS | 3 |
| MAINTENANCE | TOOLS | 11 |
| | STANDARD MAINTENANCE TIME TABLE | 12 |
| | MAINTENANCE STANDARDS AND TEST PROCEDURES | 13 |
| SYSTEM | HYDRAULIC SYSTEM | 22 |
| | ELECTRICAL SYSTEM | 23 |
| | COMPONENTS SYSTEM | 24 |
| DISASSEMBLING | WHOLE DISASSEMBLING & ASSEMBLING | 31 |
| | ATTACHMENTS | 32 |
| | UPPER SLEWING STRUCTURE | 33 |
| | TRAVEL SYSTEM | 34 |
| TROUBLESHOOTING | HYDRAULIC SYSTEM | 42 |
| | ELECTRICAL SYSTEM | 43 |
| | ENGINE | 44 |
| E/G | ENGINE | 51 |
| OPT. | | |
| DATA | SUPPORTING DATA | 71 |
| | APPLICABLE MACHINES | |

NOTE:

This Manual is prepared as a technical material in which the information necessary for the maintenance and repairing services of our hydraulic excavators are collected, and is categorized into 8 Chapters, Specification, Maintenance, System, Disassembly, Trouble-shooting, Engine, and Installation Procedures for Optional Attachment, and Supporting Data.

- The Chapter "Specification" describes the specifications for entire machine and material, which are instructive for replacement and repairing of attachments.
- The Chapter "Maintenance" describes the material, which is helpful for maintenance service and adjustments for entire machine.
- The Chapter "System" describes the operating system like hydraulic system, electric system, components, and so on.
- The Chapter "Disassembly" describes the removal and installing of assembly mounted on the upper structure and undercarriage, and the assembling and disassembling of the associated hydraulic equipment.
- The Chapter "Troubleshooting" describes how to find the fault equipment.
- The Chapter "Engine" describes the engines making use of the "Maintenance Manual" provided by the suppliers.
- The Chapter "Installation Procedures for Optional Attachment" describes the supplements added on request as required.
- The Chapter "Supporting Data" describes the contents of added material in A3 size like hydraulic circuit diagram, electric circuit diagram, and so on. It is recommended to use together with the texts in respective Chapter and Section.

This Manual may be properly revised due to the improvement of products, modification of specifications, etc. And there are cases where the system on actual machine and a part of the contents of this manual may differ due to the variations of specification by countries. For the section in which the description is hardly understood, contact our distributor.

The number is assigned to every part handled in this Manual on account of the description, but the parts, which cannot be supplied as service parts are contained. Therefore, the order must be placed with respective formal number with due confirmation on the Parts Manual for applicable machine