


2) SWING SPEED DIAL MIN ($P_{sp} = 0$ bar)



Ü SWING SPEED DIAL MAX (SWING + ARM DUMP)

