



JUNCTION CONNECTORS**Location of the junction connectors - cab****Figure 26**

113406

The location of the connectors (cab - chassis) could change to suit wiring needs.

Location of the junction connectors - chassis

Figure 27



113407