


Circuit Diagram for Undercarriage Attachments - Rear left outrigger



Undercarriage Attachments - Rear Right Outrigger

*When Fuse No.2 is not blown

*When attachment 'Mode Select' circuit is fully functional

