



AUTOMATIC TRANSMISSION / TRANSAXLE (U150E) COMPONENTS


400GZ-01



D26455




D26594




N·m (kgf·cm, ft·lbf) : Specified torque

- ◆ Non-reusable part
- ◀ Apply petroleum jelly


D03643





◆ Non-reusable part


D26720





◆ Non-reusable part

N

D26702







D03761