


2014 Lincoln Navigator

2014 TRANSMISSIONS Automatic Transmission - 6R80 - Expedition- Navigator



2. Using the Torque Converter Handle, remove the torque converter.

2014 Lincoln Navigator


2014 TRANSMISSIONS Automatic Transmission - 6R80 - Expedition- Navigator



2014 Lincoln Navigator

2014 TRANSMISSIONS Automatic Transmission - 6R80 - Expedition- Navigator

3. Remove the transmission fluid pan bolts and the transmission fluid pan.



4. Remove the transmission fluid pan gasket.