


5. ELECTRIC SYSTEM

5. Electric System

5-1 Electric Equipment of Machine

5-1-1 Parts Layout of Electrical Equipment

1) Around Engine




050819-02X00

No.	Part	No.	Part
1	Engine harness ASSY	7	Engine earth cord
2	Battery	8	Relay
3	Battery positive (+) cable ASSY	9	Slow blow fuse (40A)
4	Battery code	10	Slow blow fuse (50A)
5	Work lamp ASSY	11	Slow blow fuse (60A)
6	Work lamp harness	12	Slow blow fuse

5. ELECTRIC SYSTEM

2) Seat Mount



050820-03X00

No.	Part	No.	Part
1	Diode	6	Relay
2	Seat mount harness ASSY	7	Engine stop switch
3	Engine ECU	8	Starter switch
4	Push switch	9	LCD monitor ASSY
5	Fuse	10	Pressure switch ASSY