



Replacing Extremity Warning Light Bulb (if Equipped)



RXA0068524-UN: Extremity Warning Light



RXA0068525-UN: Remove Lens Cover



RXA0068526-UN: Remove Bulb

LEGEND:

A - Screws

B - Lens Cover

C - Light Bulb

1. Loosen screws (A).
2. Slide shield (B) away from lens cover to remove.
3. Turn lens cover (C) counterclockwise to remove light bulb (D).
4. Install new bulb in reverse order of removal

