
Record Tractor Serial Number



LV6270-UN: Tractor Serial Number Plate

Early model tractors: The serial number plate (A) is located on the right front support member of the tractor.


Later model tractors: The serial number plate (A) is located on the left front support member of the tractor.

-: Tractor Serial Number

Tractor Serial Number

OUO1043,00002A2-19-04AUG04

Record Front Axle (2-WD) Serial Number



LV630-UN: Front Axle Serial Number Plate

The front axle serial number plate (A) is located on the rear side of right-hand axle housing.

-: Front Axle Serial Number

Front Axle Serial Number

MX,INIP,FA1-19-12MAR01