



Record Engine Serial Number



RXA0082152-UN: Engine Serial Number Plate Location



RXA0112371-UN: Engine Serial Number Plate

LEGEND:

A - Engine Serial Number Plate Location

B - Engine Serial Number Plate

Identification plate location (A) is on left side of engine near starter.

-: Serial Number Plate

Serial Number

* _____ *

Engine emission tier level is identified by seventh character of the engine the engine serial number.

-: Emission Tier Level Table

<i>Emission Tier Level</i>	<i>Seventh Character of Engine Serial Number</i>
U.S. EPA Tier 3 and EU Stage III A	<i>L</i>
U.S. EPA Tier II and EU Stage II	<i>G</i>

OURX935,000018E-19-20101201