

Record Tractor Serial Number



LV4308-UN: PIN Plate


Serial number plate (A) is located on the right front support member of the tractor.

-: Tractor Serial Number

Tractor Serial Number

AG,OUO1032,2642-19-15SEP99

Record Front Axle (2-WD) Serial Number



LV4040-UN: Axle with Adjustable Steering Cylinder Shown

The front-axle serial number plate (A) is located on the right rear side of the axle housing.

-: Front Axle Serial Number

Front Axle Serial Number

AG,OUO1032,2592-19-17OCT03