

## **Record Engine Serial Number**



PULV000132-UN: 5065M and 5075M Tractors



PULV000133-UN: 5085M, 5095M, 5095MH, 5105M and 5105ML Tractors

For 5065M and 5075M Tractors: Serial number plate is located on left side of engine block near starter solenoid.

For 5085M, 5095M, 5095MH, 5105M and 5105ML Tractors: Serial number plate is located on right side of engine block behind fuel filters.

-: Engine Serial Number

**Engine Serial Number** 

AJ20558,00002CC-19-20090620

## **Record Transmission Serial Number**



PULV000135-UN: Transmission Serial Number

Serial number plate is stamped behind right 3-point hitch lift arm.

-: Transmission Serial Number

Transmission Serial Number

SH20560,0000159-19-20080414