


Alternator Identification Number Location



PY43527-UN: Alternator Identification Number Location


LEGEND:

A - Alternator Identification Number

The alternator identification number is at the rear of the housing.

PP71895,00007A6-19-20180201

Transmission Serial Number Location



PY38106-UN: OOS



PY38107-UN: Cab

LEGEND:

A - Transmission Serial Number

The transmission (drivetrain) serial number (A) is at the left-hand side of the transmission housing.

PP71895,00007A7-19-20180201