


MITSUBISHI 380 WORKSHOP MANUAL



**MITSUBISHI
MOTORS**

FOREWORD

This service manual is subdivided into various group categories. Each section contains diagnostic, disassembly, repair, and installation procedures, along with complete specifications and tightening references. Use of this manual will aid in properly performing any service necessary to maintain or restore the high levels of performance and reliability designed into this Mitsubishi vehicle.

When reference is made in this manual to a brand name, number, or specific tool, an equivalent product may be used in place of the recommended item. All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication approval. The right is reserved to make changes at any time without notice.

COPYRIGHT 2005

SERVICE DIVISION
TONSLEY PARK
SOUTH AUSTRALIA



**MITSUBISHI MOTORS
Australia Limited**

Mitsubishi Motors Australia Limited reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

© Mitsubishi Motors Australia Ltd. September 2005

GROUP INDEX

General	00
Engine	11
Engine Lubrication	12
Fuel	13
Engine Cooling	14
Intake and Exhaust	15
Engine Electrical	16
Engine and Emission Control	17
Clutch	21
Manual Transmission	22
Automatic Transmission	23
Front Axle	26
Rear Axle	27
Wheel and Tyre	31
Power Plant Mount	32
Front Suspension	33
Rear Suspension	34
Service Brakes	35
Parking Brakes	36
Steering	37
Body	42
Exterior	51
Interior and SRS	52
Chassis Electrical	54
Heater, A/C and Ventilation	55
Component Locations	70
Configuration Diagrams	80
Circuit Diagrams	90