

Engine electrical components - left side



N4A000511-UN: Left engine electrical components

LEGEND:

A - Engine oil pressure sensor plug

Go to [Section_240:Group_05](#)

N400041,0000118-19-20120816

Electrical components of dashboard and main control panel



N4A000512-UN: Dashboard

LEGEND:

- A - Small light switch
- B - Working light switch
- C - Alarm light switch
- D - High/Low beam switch
- E - Turning signal switch
- F - Horn switch
- G - Fuse box