


Record Rear Axle Housing Serial Number



TX1104588A-UN: Rear Axle Housing Serial Number Plate Location

LEGEND:

1 - Rear Axle Serial Number Plate

-: Rear Axle Housing Serial Number

Rear Axle Housing Serial Number:

The rear axle serial number plate (1) is located on the front side of rear axle housing.

OUT4001,0000A57-19-20120104

Record Mechanical Front Wheel Drive (MFWD) Front Axle Housing Serial Number



TX1107870A-UN: MFWD Front Axle Housing Serial Number Plate Location

LEGEND:

1 - MFWD Front Axle Serial Number Plate

-: MFWD Front Axle Housing Serial Number

MFWD Front Axle Housing Serial Number:

The mechanical front wheel drive (MFWD) front axle serial number plate (1) is located on the front right side of the axle.

OUT4001,0000C1A-19-20120312