

Fig.1 Disconnecting wiring harness from connection board and installing new connection board

- Use side-cutting pliers to cut off the wiring harness -2- approx.
 6 cm (-A-) past the end of the insulation -1-.
- Strip the insulation from the ends of the wires and attach the wiring connectors contained in the repair kit. Use the wiring harness repair kit VAS 1978 for this purpose.
- Install the connectors -2- from the repair kit.
- Install the new connection board -1- with the appropriate switch (depending on colour; supplied with the repair kit).

— 72-145 **–**

- Install the cover -1-.

- Clamp the connector -3- between switch unit and panel.
- Clamp the wiring harness -2- into the groove on the switch unit.







